

SL T2™ VISOR CLIPS

ENGINEERED PROTECTION THAT SURROUNDS

Precision-engineered visor attachment clips designed for SL T2 Safety Helmets. They seamlessly slide into the front accessory slot, allowing swift visor control with the top button. Whether switching between clear and gray or ensuring optimal safety, the SL T2 Visor Clips deliver functionality without compromise. Made exclusively for visors.



FEATURES

Effortless Attachment: Attach and detach the visor to the clips with ease, thanks to quick-release/connect design that ensures a snug and secure fit every time

User-Friendly Design: Clips allow for ratchet visor adjustments, making use intuitive and efficient

i HPT2CLIPS are replacement visor clips sold separately from the SL T2 Safety Helmet.

Updated as of 06.24

INSTRUCTIONS

To Attach Clips to Helmet

1. Check for L and R indicators on the backside of each clip.
2. Place the left and right clips in the corresponding front accessory slots of the helmet.

To Attach Visor to Clips

1. Position the visor over the holes on the clips on the front accessory slots.
2. Press in to ensure a secure fit.

To Remove Visor from Clips

1. Press the button labeled "PUSH" on the top of the clip to release the visor.
2. Gently pull the visor away from the clips.

To Remove Clips from Helmet

1. Simply pull up on clips to detach them from helmet.



TOOLS AT YOUR FINGERTIPS

Learn more about the SL T2 Helmet and Accessories